


Instruction Manual

Model no. PT-60

Maverick Pocket Knife Thermocouple Thermometer + 3 Tools

Congratulations on the purchase of your new Pocket Knife Thermocouple Thermometer + 3 Tools.



**POWER ON/OFF**  
Press (⏻) button once to power on  
Press & hold the (⏻) button 3 seconds to turn off the thermometer.

**C/F (CALIBRATION)**  
Press (C/F) for Fahrenheit or Centigrade for temperature reading.  
Press & hold (C/F) button for 5 sec for Re-Calibration.

**HOLD**  
Press (H) once to hold temperature recorded,  
press (H) again to un-hold

**PROBE RELEASE**  
The thermometer probe is tucked into it's groove so you can put it into your pocket without snagging the inside of your pocket. To open the probe, you need to slide the probe release on the end of the thermometer 1/4" follow (H) direction which will push out the probe so you can grab it with fingertip and open fully. When closing the probe be sure to push the probe all the way back into it's groove.

1. To insert the batteries  
Open the battery door, insert two AAA batteries with the correct battery polarity.

2. Temperature Scale  
To select temperature reading in Fahrenheit or Centigrade by pressing (C/F) button.

3. Getting Started  
Press (⏻) button once to turn on the thermometer.

Press (H) button once lock the current temperature displayed on thermometer.  
The LCD will show "HOLD" icon. Press again to release the locked temperature reading, the "HOLD" icon will be off and back to current temperature display.

USDA SAFE FOOD TEMPERATURES\*

MEAT	WELL / DONE	MEDIUM	MEDIUM RARE	RARE
BEEF	160F / 71C	145F* / 63C	135F* / 57C	125F* / 52C
VEAL	160F / 71C	145F* / 63C	135F* / 57C	125F* / 52C
LAMB	160F / 71C	145F* / 63C	135F* / 57C	125F* / 52C
POULTRY	165F* / 74C	—	—	—
PORK	160F / 71C	145F* / 63C	—	—
GROUND MEAT	160F / 71C	—	—	—
FISH	145F / 63C	—	—	—

4. RE-CALIBRATION of Thermometer  
- Make ice bath with 3 parts ice and 1 part cold water.  
- Insert the probe tip into center of ice bath.  
- Press and hold (C/F) button for 5 seconds until the unit show "CAL"  
- The thermometer will start calibration range from -3C /+26.6F to +2C /+35.6F to an accurate 0C /+32F  
Note: Water boils at 208 F/97.8 C at 2000 ft above sea level



5. Battery Status  
When the voltage on battery is low, Low Battery Indicator will be shown on LCD. Please replace with new batteries.



6. Manual / Auto Power Off  
- Press and hold (⏻) button for 3 seconds to turn off the thermometer for power saving.  
- Press (⏻) button again to turn on the thermometer.  
- The thermometer will automatically power off if no buttons are pressed for two minutes.

**SPECIFICATIONS:**  
Operating Range : -4°F to 572°F / -20°C to +300°C  
Display Range : -4°F to 572°F / -20°C to +300°C  
Power : 2 x AAA

**CARE OF YOUR PRODUCT**  
Don't touch the probe tip with bare fingers after use to avoid burning fingers.  
Don't put the thermometer probe inside the oven or microwave oven and always keep at least 6" away from any heat source.  
The thermometer probe is made of food-grade stainless steel and is designed for instant measurement only.  
Don't measure temperatures above 300°C /572°F. Never burn probe directly over fire. Doing so, the thermometer screen will show "HI" and continuously using at this temperature will cause permanent probe damage.  
Use damp cloth or sponge to clean the probe and dry thoroughly after cooking.  
Don't subject the thermometer to extreme temperatures, humidity or severe shock.  
Don't clean the case with any corrosive materials such as perfume, alcohol or cleaning agent or abrasives. Keep the batteries, stainless steel probe away from children.  
The thermometer probe is tucked into it's groove so you can put it into your pocket without snagging the inside of your pocket. To open the probe you need to slide the probe release on the end of the thermometer 1/4" to the right which will push out the probe so you can grab it with fingertip and open fully. When closing the probe be sure to push the probe all the way back into it's groove.

Disposal of Your Old Product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.



Please inform yourself about the local separate collection system for electrical and electronic products.  
Please act according to your local rules and do not dispose of your old products with your normal household waste.  
The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

Disposal of Flat Batteries / Accumulators

You, as the end user, are legally obliged (Battery Ordinance) to return all flat batteries and rechargeable batteries. Disposal in the household waste is prohibited.  
"European Directive 2006/66/EC" Batteries, including rechargeable batteries, which contain hazardous substances are marked by symbols, which indicate the prohibition of disposal in the household, waste.



The designations for the heavy metals concerned are as follows:  
Cd = cadmium, Hg = mercury, Pd = lead. You can return flat batteries / rechargeable batteries free of charge to the collection points in your community or anywhere where batteries / rechargeable batteries are sold. You thus fulfill your statutory obligations and help protect the environment.

MAVERICK LIMITED 90 DAY WARRANTY

Maverick Industries Inc. warrants this product to be free of defects in parts, materials and workmanship for a period of 90 days, from date of purchase. Should any repairs or servicing under this warranty be required, contact Maverick Customer Service by mail or phone for instructions on how to pack and ship the product to Maverick's National Service Center located as follows:

Maverick Customer Service  
94 Mayfield Ave.  
Edison NJ 08837

Telephone: (732) 417-9666

Hours: Weekdays 8:30 AM- 4:30 PM

Do not send any parts or product to Maverick without calling and obtaining a Return Authorization Number and instructions.

This warranty is VOID if instructions for use are not followed; for accidental damage; for commercial use; for damage incurred while in transit; or if the product has been tampered with.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

www.maverickhousewares.com