





INSTRUCTIONS

To adjust the flame

- 1. Locate the flame adjuster on the base of the lighter indicated by the + and - symbols.
- 2. Rotate the adjuster in the direction of the + symbol to increase the height of the flame and the symbol to decrease it.
- 3. Check the flome height after adjustment.
- 4. Repeat as needed to achieve the desired height.
- 5. Extend the tip by sliding in or out as desired.

To refill the lighter:

- 1. Invert the lighter.
- 2. Locate the inlet valve on the bottom of the lighter.
- 3. Using a bulane canister, depress the nozzle over the lighter inlet valve. Make, sure the nozzle interlocks with the inlet valve before beginning to pump the canister.
- 4. Pump the canister in short bursts, about 3-4 times.
- 5. Allow the lighter to rest for 5 minutes before igniting.

WARNING

DANGER - EXTREMELY FLAMMABLE. CONTENTS UNDER PRESSURE. DO NOT USE NEAR SPARKS OR OPEN FLAME. DO NOT PUNCTURE OR INCINERATE CONTAINER OR STORE AT TEMPERATURES ABOVE 120°F. KEEP OUT OF THE REACH OF CHILDREN. IGNITE AWAY FROM FACE AND CLOTHING. BE SURE FLAME IS OUT AFTER USE.

One Year Warranty

Maverick Industries warrants this product to be free from defects in material and workmanship for one year from the date of the purchase. Upon return of the product prepaid to Maverick Industries, 94 Mayfield Avenue, Edison, NJ 08837, we will repair it or replace it at our option free of charge.



Made in China for Maverick Industries, Inc. Edison, NJ 08837